



TRIDENT TRF 924

65-125kVA Transformer Cabinet

USER MANUAL

No reproduction of any part of this manual, even partial, is permitted without the authorization of Dual-Lite. Dual-Lite reserves the right to modify the product described herein, in order to improve it, at any time and without notice.

Hubbell Lighting, Inc
701 Millennium Blvd
Greenville, SC 29607
Web site: www.dual-lite.com/

Thank you for choosing our product.

SAFETY WARNINGS



IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

This manual contains important instructions that you should follow during installation and maintenance of the transformer cabinet. Please read all instructions before operating the equipment and save this manual for future reference.

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

- Do not use outdoors.
- Do not route wiring across or near hot surfaces.
- Do not install near gas or electric heaters.
- Equipment should be installed where it will not readily be subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Do not use this equipment for other than intended use.
- This equipment connects to the output of an uninterruptible power supply. Hazardous voltages may be present even when the electrical supply to this equipment is turned off.
- If equipped with a maintenance bypass switch, control connections between this equipment and the ups must be present to prevent the possibility of backfeed.
- Read and follow the instructions that came with the associated UPS or emergency lighting system before operating this equipment.

Table 1 - Symbols

	Danger / Risk of Electric Shock <i>This symbol indicates possibility of serious injury or substantial damage to the unit, unless adequate precautions are taken.</i>
	Warning <i>This symbol indicates important information which must be understood and any stated precautions taken</i>
	Note

DANGER



This equipment contains lethal voltages. All repairs and service should only be performed by authorized service personnel. There are no user serviceable parts inside this equipment. Operation of switches and breakers require access to the cabinet interior and should only be performed by qualified personnel exercising appropriate caution.

WARNING



This equipment connects to the output of a UPS which contains its own energy source (batteries). The UPS output may carry live voltage even when the UPS is not connected to an AC supply.

To reduce the risk of fire and electric shock, install this equipment in a humidity controlled, indoor environment, free of conductive contaminants. Do not operate near water or excessive humidity (95% maximum). If condensation is present, the equipment must be allowed to completely dry before operation.

Input and output circuit breakers must be provided by others. This circuit protection must meet the input and output protection requirements as shown in

Table 6 of this manual.

WARNING



The UPS associated with this equipment contains batteries. Batteries can present a risk of electrical shock or burn from high short circuit current. Observe proper precautions. Servicing should only be performed by qualified service personnel knowledgeable of batteries and the required precautions. Keep unauthorized personnel away from batteries. Read, understand, and follow all instructions in the ups manual before attempting any operations involving the battery.

Table of Contents

SAFETY WARNINGS.....	iii
1 Introduction	1
1.1 Overview.....	1
1.2 Applicability.....	2
2. Cabinet Setup	3
2.1 Inspecting the Equipment	3
2.2 Floor Loading.....	3
2.3 Clearances	3
2.4 Unloading the Cabinet(s)	4
2.5 Attaching the Cabinet to the UPS	5
3. Electrical Installation.....	6
3.1 Overview.....	6
3.2 Wiring Preparation	6
3.3 Wiring Installation	8
3.4 Control Connections (MBS Arrangement Only)	9
3.4.1 Connections Between the Maintenance Bypass Switch and the UPS (MBS Arrangement Only).....	9
3.4.2 Terminal Strip Torque Requirements (MBS Arrangement Only)	9
3.4.3 Switch Settings (MBS Arrangement Only).....	10
4. Backfeed Protection (MBS Arrangement Only)	12
4.1 Remote EPO (Emergency Power Off) (MBS Arrangement Only)	12
5. Operation (MBS Arrangement Only)	14
5.1 To transfer from normal mode on the UPS to maintenance bypass—.....	15
5.2 To transfer from MBS to normal mode—	15
5.3 Normal start-up with load unpowered—.....	15
5.4 Need to get power to the load, but the condition of the UPS is uncertain—	15
5.5 Need to operate the UPS as part of maintenance, but wish to maintain power to	16
5.6 Potential Problems:.....	16
5.7 REPO (MBS Arrangement Only)	17
6. Maintenance.....	19
7. Technical Specifications.....	20
Table 1 - Symbols	iii
Table 2 - Model Floor Loadings.....	3
Table 3 - Maintenance Bypass Switch States	17
Table 4 - Maintenance Bypass Switch State Change Procedures	18
Table 5 - Technical Specifications.....	20
Table 6 - Wire Size Requirements and Maximum Current Ratings	21
Table 7 - Terminal Tightening Torques	22
Figure 1 – Outline Drawing.....	1
Figure 2 - Pallet Mounting Hardware.....	4
Figure 3 - Cabinet to Cabinet Mounting Hole Locations	5
Figure 4 - Inside Front View of Transformer Cabinet.....	7
Figure 5 - Cabinet Top Conduit Locations	7
Figure 6 - Options Control Board Assembly	10
Figure 7 - Customer Low Voltage Connection Terminal Block	11
Figure 8 - Circuit Breaker Sequence Label	17

1 INTRODUCTION

1.1 Overview

The Transformer Cabinet for 65 kVA, 80 kVA, 100 kVA, and 125 kVA is a steel cabinet that can either attach to the left side of the UPS cabinet or remain free standing. The purpose of the Transformer Cabinet is to allow operation of a UPS 480 V in/out with 208 V input and/or output and/or provide an output neutral when an input neutral is desired but not available. See **Figure 1** for the outline drawing of the Transformer Cabinet.




Figure 1 – Outline Drawing

1.2 Applicability

When present, the input transformer is always a 208 V primary to 480 V secondary autotransformer with a circuit breaker between the transformer and the UPS. If input is wye configured, the input neutral connects to the autotransformer and the ground bond in the UPS is removed. If input is delta configured, the input neutral terminal is not used.

- An autotransformer with 208 V primary to 480 V/277 V secondary is used for the following:
 - 208 V wye to 208 V/120 V wye
 - 208 V wye to 480 V/277 V wye
 - 208 V delta to 208 V delta
 - 208 V delta to 480 V delta

The output transformer always has a breaker between the UPS output and the transformer primary. There are three configurations of three phase output transformers available for use in the Transformer Cabinet:

- An autotransformer with 480 V primary to 280 V/120 V secondary is used for the following:
 - 208 V wye to 208 V/120 V wye
 - 480 V wye to 208 V/120 V wye
 - 208 V delta to 208 V delta
 - 480 V delta to 208 V delta
- An isolation transformer with 480 V primary to 208 V/120 V secondary is used for the following:
 - 208 V delta to 208 V/120 V wye
 - 480 V delta to 208 V/120 V wye
- An isolation transformer with 480 V primary to 480 V/277 V secondary is used for the following:
 - 480 V delta to 480 V/277 V wye

2. CABINET SETUP

This SECTION describes:

- Equipment inspection
- Floor loading and clearances
- Removing and replacing the cabinet panels
- Unloading the cabinet(s)
- Attaching the cabinet to the UPS

If a Maintenance Bypass Switch (MBS) is installed, the site where the equipment is located must be such that the required control connections between the cabinet and the UPS are no greater than 30 feet or 10 meters in length.

2.1 Inspecting the Equipment

If any equipment has been damaged during shipment, keep the shipping and packing materials for the carrier or place of purchase and file a claim for shipping damage. If you discover damage after acceptance, file a claim for concealed damage.

To file a claim for shipping damage or concealed damage: 1) File with the carrier within 15 days of receipt of the equipment, 2) Send a copy of the damage claim within 15 days to your service representative.

2.2 Floor Loading

When planning the installation, consider the battery cabinet weight for floor loading. The strength of the installation surface must be adequate for point and distributed loading. The approximate weights are shown in the following table.

Table 2 - Model Floor Loadings

STANDARD MODEL FLOOR LOADING		
MODEL	MAXIMUM WEIGHT	POINT LOADING
w/ autotransformer	1130 lbs (513 kg)	8.6 lb/in ² (0.6 kg/cm ²)
w/ (2) autotransformers	1760 lbs (798 kg)	13.5 lb/in ² (0.9 kg/cm ²)
w/ auto & isolation transformers	2100 lbs (952 kg)	16 lb/in ² (1.1 kg/cm ²)
w/ isolation transformer	1470 lbs (667 kg)	11.2 lb/in ² (0.8 kg/cm ²)

2.3 Clearances

The following clearances are recommended for the Transformer Cabinet:

From Front of Cabinet	36" (91.4 cm) working space
-----------------------	-----------------------------

2.4 Unloading the Cabinet(s)

The following tools are required for unloading the cabinet(s):

- Wrenches for 3/8" lag bolts.
- Forklift or pallet jack

WARNING



The cabinets are heavy (see **Table 2**). Unloading the cabinets requires at least two people to safely remove the cabinets from the pallet.

To remove the Transformer Cabinet from the ship pallet:

1. Make sure the forklift is rated for the cabinet weight.
2. Make sure the path traveled has sufficient support for the combined weight of the forklift and the cabinet.
3. Make sure forks are at maximum separation.
4. Use a very strong ratchet strap (or similar device) of sufficient strength to tie the upper part of the cabinet to the forklift tower before moving.
5. Keep people out of the fall zone. If the cabinet topples over, stand clear
6. With a Phillip's screwdriver, remove the two kick panels. These will be remounted when the cabinet is in place.
7. Remove all banding, wrapping and foam protection.
8. Remove the six 3/8" lag bolts securing the cabinet to the pallet. See **Figure 2**.



Figure 2 - Pallet Mounting Hardware

9. Lift the cabinet with a forklift one to two inches (1"-2" [2.5-5cm]) above the pallet.
10. Slide the pallet completely away from the raised cabinet.
11. Carefully move the cabinet to the desired location and slowly lower the cabinet to the floor or other appropriate flat surface.
12. Remount the two kick panels.

2.5 Attaching the Cabinet to the UPS

The Transformer Cabinet was constructed so that it can be mounted to the side of the UPS cabinet if desired. To attach the Transformer Cabinet to the UPS Cabinet:

1. Remove left side panel of UPS and save hardware.
2. Butt right side of Transformer Cabinet up against the left side of the UPS.
3. Bolt the cabinets together at (6) locations with the supplied 5/16 hardware through the slots noted as "A" in **Figure 3**.
4. Mount left side panel of UPS on the left side of the Transformer Cabinet using the hardware from the UPS.




Figure 3 - Cabinet to Cabinet Mounting Hole Locations

2.6 Free-Standing Cabinet

The Transformer Cabinet can be used as a free-standing cabinet, but side panels must be ordered separately and attached to both sides of the cabinet.

3. ELECTRICAL INSTALLATION

3.1 Overview

Each of the pieces of equipment covered by this manual has four sets of power connections:

1. Input from the power source, typically, from the electric utility.
2. Power routed to the input of the UPS.
3. Power from the output of the UPS.
4. Power to the load

There are four control connections between the Transformer Cabinet and the UPS that must be made. The required control connections (MBS arrangement only) are described later in this section.

WARNING



Only qualified service personnel (such as a licensed electrician) should perform the installation and initial startup. There is a risk of electrical shock.

3.2 Wiring Preparation

1. Verify that the equipment is the proper type. While the Transformer Cabinet can come in a variety of configurations, the UPS must be properly configured (refer to the UPS manual).
2. Plan the location of conduits. Conduit landing plates are provided at the top, rear, and bottom of the cabinet. As noted, there are four sets of power connections. If the MBS arrangement is included, one set of control connections will also exist. The low voltage control connection must be routed through the top front cover of the cabinet, seven (7) inches (178 mm) minimum from the power wiring to ensure physical separation between them and the power wiring. The power wiring may enter the cabinet through the top rear cover, the rear or bottom plates. See **Figure 5**.
3. All wiring is to be in compliance with all applicable codes.
4. Verify that the source circuit capability is in compliance with the requirements shown in **Table 6**.
5. Select wire size in compliance with **Table 6**.




Figure 4 - Inside Front View of Transformer Cabinet




Figure 5 - Cabinet Top Conduit Locations

3.3 Wiring Installation

1. Switch off utility power to the distribution point where the UPS will be connected. Be absolutely sure that there are no hazardous voltages present. Use appropriate procedures to assure safety.
2. Remove as many panels as needed for adequate access for wiring the cabinet. Open the front door of the Transformer Cabinet.
3. Connect wires from the "**TO UPS INPUT**" terminal block to the input terminals in the UPS. (Refer to the UPS manual). The wire must be in compliance with **Table 6** and the terminals must be torqued in compliance with **Table 7**. Make sure that phase A connects to phase A and so on.
4. Connect wires from the "**FROM UPS OUTPUT**" terminal block to the output terminals in the UPS. (Refer to the UPS manual). The wire must be in compliance with **Table 6** and the terminals must be torqued in compliance with **Table 7**. Make sure that phase A connects to phase A and so on.
5. Connect wires from the "**OUTPUT TO LOAD**" terminal block to the load. The load may be an external distribution panel, etc. If neutral is not needed by the load, then it does not need to be supplied. The wire must be in compliance with **Table 6** and the terminals must be torqued in compliance with **Table 7**. Make sure that phase A connects to phase A and so on.
6. Verify that the input power source is not powered. Connect wires from the "**UTILITY INPUT**" terminal block to the input source power from the building distribution. The wire must be in compliance with **Table 6** and the terminals must be torqued in compliance with **Table 7**. Make sure that phase A connects to phase A and so on. The source needs to have A-B-C phase sequence. If not, exchange two of the phase connections to correct this.
7. **MBS Arrangement Only**: A set of control connections must be installed from the "**CUSTOMER LOW VOLTAGE CONNECTION TERMINAL BLOCK**" to the Remote Commands and Alarm Connections in the front of the UPS cabinet. These control wires must be physically separated from any power wires. The length of the control wires is limited to 30 feet or 10 meters. See Section **3.4 Control Connections (MBS Arrangement Only)** for wiring details.
8. Check all work. Replace the panels that were removed for access.

3.4 Control Connections (MBS Arrangement Only)

Four control connections must be made between the Transformer Cabinet with MBS arrangement and the UPS in order to provide backfeed protection, a required safety feature. There is also a provision to provide Remote Emergency Power Off (REPO). REPO causes the output breaker to trip, thereby removing power from the load. If the bypass path is active, then REPO trips the bypass breaker, removing power from the load.

The wiring to these low voltage (“ELV”) connections must be kept separated from the higher voltage wiring. Refer to **Figure 7** regarding the Low Voltage Terminal Block and to the UPS manual that shows the connection point in the UPS.

3.4.1 Connections Between the Maintenance Bypass Switch and the UPS (MBS Arrangement Only)

Since these wires affect the operation of the UPS, they should be protected. Running them in conduit is recommended. It is also recommended that the wires are shielded twisted pairs. Alpha 6010C is a shielded cable with three twisted pairs and is available from a number of sources in various spool lengths.

Two pairs are required:

Pair 1 -- First wire from terminal 3 of the Low Voltage Connection Terminal Block (LVTB) of the Transformer Cabinet with MBS arrangement to terminal 11 of the Remote Commands and Alarms Connections on the UPS (RCA-UPS). Second wire from terminal 4 of LVTB to terminal 12 of RCA-UPS.

Pair 2 – First wire from terminal 10 of LVTB to terminal 1 of RCA-UPS. Second wire from terminal 11 of LVTB to terminal 2 of RCA-UPS.

Figure 7 is an electrical wiring schematic summarizing the connections to the Low Voltage Connection Terminal Block.

The REPO switch connections are also shown. Please note that typically only one of the REPO switch contacts is connected, depending on user preference, but both are shown to illustrate the wiring. The normally open switch connects across terminals 5 and 6 while the normally closed switch connects across terminals 8 and 9. Terminal 7 has a limited amount of unregulated dc power available to power an LED lamp to permit the use of a lighted switch for REPO. Contact Dual-Lite for details if you desire to use this feature. See **Section 3.4.3 Switch Settings (MBS Arrangement Only)** to properly configured the Options Control Board in the Transformer Cabinet for the normally closed REPO switch to work.

3.4.2 Terminal Strip Torque Requirements (MBS Arrangement Only)

The terminals on the Customer Low Voltage Connection Terminal Block must be torqued to 5.3 to 7.0 inch-lbs. The terminals on the Control Connections (on the UPS) must be torqued to 4.4 inch-lbs.

3.4.3 Switch Settings (MBS Arrangement Only)

Switch "S2" on the Options Control Board (refer to **Figure 6**) is a four position "DIP" switch that has four small rocker switches. Pushing on the top half of each switch section closes the switch and turns it ON, pushing on the lower half turns the switch OFF. There are labels on the board to help identify the switch section.

The first section "PLT" enables "Power Loss Trip" (or Manual Restart), and should be OFF unless you want the Bypass and Inverter Output Breakers to trip on loss of power.

The second section "NCR" enables the Normally Closed REPO input and should be OFF unless there is a normally closed REPO switch connected.

The third section "OTT" is not implemented and should be turned OFF to avoid confusion.

The fourth section is not used and should be turned OFF to avoid confusion.




Figure 6 - Options Control Board Assembly

**REMOTE COMMANDS AND ALARMS CONNECTIONS
ON FRONT OF UPS BEHIND DOOR**




Figure 7 - Customer Low Voltage Connection Terminal Block

4. BACKFEED PROTECTION (MBS ARRANGEMENT ONLY)

In some of the possible combinations of switch positions for the MBS, the output of the UPS could be connected to the input to the system. If the UPS is in Normal mode (the load is being supplied power from the inverter), this could cause damage to the UPS. Further, if the input to the system is not powered, the inverter could run on battery and supply voltage to the input of the system. Service personnel working on the line feeding the input to the system (or the line feeding that line, etc.) could be subjected to hazardous conditions. Imagine an electrician opening the supply breaker feeding the MBS and expecting that line to be safe to work on. A requirement for UPS design is that backfeed must be prevented.

Since the Transformer Cabinet with MBS arrangement is external to the UPS, the UPS cannot provide backfeed protection without receiving information concerning the position of the switches of the MBS. An additional requirement is that backfeed protection be provided with the failure of any one component. That means that the protection must have redundancy in the method.

The redundant methods implemented in the MBS are as follows:

1. If the UPS Output Breaker (Breaker #3) and the Bypass Breaker (Breaker #2) are both closed, the UPS is commanded to go to Bypass mode, no matter what. If the UPS was operating on battery due to an input source failure, the load will lose power, but it will be impossible for the UPS to cause backfeed. This method requires a signal from the MBS control to the UPS control via a pair of wires.
2. Unless the UPS is On Bypass OR the UPS Output Breaker (Breaker #3) is open, the trip mechanism of the Bypass Breaker (Breaker #2) will be activated, preventing it from closing. This requires a signal from the UPS control to the MBS control via a pair of wires.

As is explained in **Section 5. Operation (MBS Arrangement Only)**, the proper procedure for putting the MBS into the Bypassed mode requires that the user first put the UPS in "Manual" Bypass Mode. Thus the signal that the UPS is On Bypass will be present and the Bypass Breaker in the MBS can be closed. Further, closing the Bypass Breaker will assert the command to the UPS to go to bypass, but this will have no effect as the UPS is already in bypass. That is, if the user follows the correct procedures for operating the MBS, these backfeed prevention schemes will be completely transparent.

4.1 Remote EPO (Emergency Power Off) (MBS Arrangement Only)

Some applications (notably, data centers) require that there is a provision to remotely shut down power to the equipment powered by the UPS. Typically, this "remote" control is a red button switch located next to the exit and wired to the UPS. The Transformer Cabinet with MBS arrangement is equipped with a Remote EPO input that causes both the Bypass Breaker (Breaker #2) and the UPS Output Breaker (Breaker #3) to trip when a REPO switch activation is sensed. This way, power is interrupted regardless of which breaker was actually supplying current to the load. It may be desirable to also shut down the UPS upon activation of the EPO function. This requires a separate switch contact (NC) wired in accordance with the restrictions in the UPS manual.

Note that the UPS has a front panel "EPO" switch. Pressing this switch will cause the UPS to shut off immediately, but its action is only local. That is, it affects the UPS, but there is no way for this switch to have a direct operating effect on the Transformer Cabinet with

MBS arrangement. (There are some indirect possibilities. For example, stopping the UPS by pressing the EPO could cause the On Bypass signal from the UPS to the Transformer Cabinet with MBS arrangement to change, tripping the Bypass Breaker if the UPS Output Breaker is also closed. These indirect actions will not affect system operation if the system is operated according to the procedures in **Section 5. Operation (MBS Arrangement Only).**)

Some users prefer to use a normally open switch in the REPO system; others prefer a normally closed switch. Inputs for both types of switches are provided in the Transformer Cabinet with MBS arrangement, but the normally closed function has to be enabled by operating a small rocker switch on the Options Control Board. This is to avoid the problem of not being able to operate the system if the normally closed circuit is missing, as when the user only chooses to use the normally open configuration, or when the user does not choose to use the REPO system at all.

Historically, REPO systems have caused a lot of confusion due to systems not being capable of operation due to a false signal from the REPO switch(es). To address this issue, the Options Control Board has a yellow LED lamp (DS1 in the upper right corner of **Figure 6**) that indicates that the REPO has been activated. The logic that operates the lamp latches the indication, so it is possible to determine that the REPO was activated at some time since power was applied to the system. The latched indication can be reset by pressing S1 on the Options Control Board.

Some users prefer that power not be restored to the load automatically, if lost, so that they can manually reapply power to the connected loads using a defined sequence. There is a rocker switch on the Options Control Board that selects this capability. If the switch is ON and power is lost (both the utility input power to the cabinet and the power from the UPS), Breakers #2 and #3 will both trip, assuring that the load cannot be powered without manually closing one of these breakers. Sometimes this feature is called "Manual Restart".

5. OPERATION (MBS ARRANGEMENT ONLY)

Refer to the User's Manual for the UPS for instructions on operating the UPS part of the system. **If the UPS is part of a parallel system, special operating instructions apply.**

The purpose of the Maintenance Bypass Switch (MBS) is to facilitate servicing the UPS without removing power from the load. The main functional components of the MBS are three circuit breakers that are used as disconnect switches. We will designate them "BKR1", "BKR2", and "BKR3", but they are labeled "1", "2", and "3" above the breaker handles on the front inner cover of the cabinet. The breakers each have three positions: off (down), on (up), and tripped (in between off and on). To turn on a tripped breaker, reset the breaker by pushing the handle down to the off position, and then raise it to the on position. If a breaker will not reset or trips as being turned on, the backfeed prevention interlock is active and the proper conditions (as described below) will have to be present before the breaker can be operated. When closed, BKR1 supplies power from the supply (utility) to the bypass input of the UPS. For single input UPS configurations, it also supplies power to the rectifier input. When closed, BKR3 connects the output of the UPS to the load. When closed, BKR2 bypasses the path through BKR1, the UPS, and BKR3 and connects the supply directly to the load. BKR2 and BKR3 must never be closed at the same time unless the UPS is in bypass mode. It does not matter which type of bypass, but bypass via SWMB is the simplest to engage. There are signals that support an interlock function to prevent BKR2 from being closed unless BKR3 is open or the UPS is in bypass mode. For the UPS to be able to issue this signal, the UPS controls must be powered. Always observe proper switching sequence to avoid loss of power to the load. Common switching operations are also described, below. There are also some problem scenarios listed.

The three switches (Breaker 1, Breaker 2, and Breaker 3) have eight possible combinations or "States". **Table 3** lists all of the possible states. Note that one possibility (Breaker 1 open, Breaker 2 and Breaker 3 closed) is forbidden as unexpected system behavior could result, including loss of power to the load. The Overlap State is a transient state. It is the "make" before the "break". Time spent in this state should be kept to a minimum as external events could lead to tripping Breaker 2, possibly interrupting power to the load. Also, please note that the UPS does not condition the power to the load while in bypass and that battery back-up is not available while in bypass.

To avoid damage to the UPS and to avoid interrupting power to the load, the procedures listed in **Table 4** must be used to change from one state to another. The MBS is equipped with a label (see **Figure 8**) that describes the breaker sequences for two common operations. The "To place load on maintenance bypass" sequence describes going from Normal State to Overlap to UPS Unloaded to Maintenance. The "To place load on UPS" sequence describes going from Maintenance State to UPS Unloaded to Overlap to Normal.

5.1 To transfer from normal mode on the UPS to maintenance bypass—

1. Verify that the bypass source is satisfactory: at minimum, verify that the bypass source lamp (LED1 at upper left) on the front panel of the UPS is steady green and that the legend “BYPASS VOLTAGE FAIL” is not present on the display. If the load is already being supported by the Static Bypass, the yellow “Load on Bypass” lamp (LED4, upper right) will be steady (or flashing if the load exceeds the UPS rating). Refer to the UPS manual regarding the indicators.
2. Close SWMB on the UPS. After SWMB is closed, the yellow “Load on Bypass” lamp will flash and the inverter will stop and battery supported operation is no longer possible.
3. Close BKR2.
4. Open BKR3.
5. Shut down the UPS, if desired, by opening SWOUT, SWIN, SWBY, and open the Battery Disconnect(s). Optionally open SWMB.
6. If the UPS is shut down, open BKR1. The UPS is completely de-energized at this point.

5.2 To transfer from MBS to normal mode—

1. Close BKR1.
2. On the UPS, verify that SWMB is closed, if not, close it.
3. Close SWBY, SWIN, and SWOUT. Wait 5 seconds.
4. Close BKR3.
5. Open BKR2.
6. Open SWMB. The UPS should start and operate normally.
7. When the display no longer shows: “Wait: DO NOT connect the BATTERY”, the disconnect breakers in each battery cabinet should be closed. Refer to the UPS manual for the proper procedure for connecting the battery.

5.3 Normal start-up with load unpowered—

1. Verify that BKR2 is open; open it if closed.
2. Verify that SWBY is open.
3. Close BKR1 and BKR3.
4. Perform a normal UPS start-up as per the UPS manual.

5.4 Need to get power to the load, but the condition of the UPS is uncertain—

1. Verify that the load is truly not powered.
2. Verify that the utility source is suitable (applying power to the load using the MBS is at the operator’s risk).
3. Verify that BKR1 and BKR3 are open; open them if necessary.
4. Close BKR2. The load is now powered via the MBS. The UPS is not functional and battery supported operation is not possible.

5.5 Need to operate the UPS as part of maintenance, but wish to maintain power to load—

1. If UPS is running, perform transfer from normal mode to MBS, see **Section 5.1 To transfer from normal mode on the UPS to maintenance bypass—**. After opening BKR3, the UPS can be left powered (via BKR1) and/or its mode can be changed as desired.
2. If BKR2 is already closed, close BKR1 to apply power to the UPS. If the UPS is dual input, there is another supply that must be applied to power the rectifier.
3. There is some risk in starting the UPS while the load is powered via BKR2 (MBS mode). A fault in the UPS could cause the upstream circuit protection (circuit breaker or fuse) to operate, removing power from both the faulted UPS input and the MBS input and, therefore, the output.

5.6 Potential Problems:

MBS will not allow BKR2 to close—

1. Check to see that the UPS is on bypass (SWMB is closed).
2. The UPS controls must be powered (BKR1 and SWBY should be closed).
3. Verify that the backfeed prevention interlock signals were properly wired as part of the installation and that this wiring has not been damaged.

BKR2 in the MBS trips when power is applied—

1. This is likely due to a procedural error. Note that BKR2 and BKR3 must not be closed at the same time unless the UPS is powered and the UPS is in bypass mode.
2. It is likely that BKR3 is closed and the backfeed prevention interlock function is preventing BKR2 from staying closed.
3. Since the UPS is not powered, the signal that indicates that the UPS is in bypass mode cannot be generated.
4. Open BKR3 and close BKR2. BKR2 should close and stay closed.
5. If power to the UPS is not required, open BKR1.




Figure 8 - Circuit Breaker Sequence Label

5.7 REPO (MBS Arrangement Only)

User provided switch circuits are required to activate the REPO. Upon activation, the REPO function trips Breaker 2 (if closed) and Breaker 3 (if closed), interrupting power to the load. For details on how to connect to the REPO input(s) refer to Section 4 of this Manual.

To restart the system after activation of the REPO, make sure that the REPO switch is in the non-activated state before continuing. Then, use the Startup procedure for the UPS.

Table 3 - Maintenance Bypass Switch States

Breaker 1 = Left hand breaker = UPS Input

Breaker 2 = Center breaker = Bypass

Breaker 3 = Right hand breaker = UPS Output

State Name	Breaker 1	Breaker 2	Breaker 3	Adjacent State(s)
Normal	closed	open	closed	Overlap, Test UPS, Test Battery
Overlap	closed	closed	closed	Normal, UPS Unloaded
UPS Unloaded	closed	closed	open	Overlap, Maintenance
Maintenance	open	closed	open	UPS Unloaded, Load Off
Load Off	open	open	open	Maintenance, Test UPS
Test UPS	closed	open	open	Load Off, Normal
Test Battery	open	open	closed	Normal
Not Allowed	open	closed	closed	(none)

Table 4 - Maintenance Bypass Switch State Change Procedures

(refer to **Table 3** for description of states)

From State	To State	Procedure
Normal	Overlap	1. Select Manual Bypass Mode on UPS. 2. Verify load on bypass by observing front panel of UPS. 3. Close Breaker 2.
Overlap	Normal	1. Open Breaker 2. 2. Select Automatic Transfer to Inverter Mode on UPS.
Overlap	UPS Unloaded	Open Breaker 3.
UPS Unloaded	Overlap	1. Select Manual Bypass Mode on UPS. 2. Verify load on bypass by observing front panel of UPS. 3. Close Breaker 3.
UPS Unloaded	Maintenance	1. Turn Off UPS 2. Open Breaker 1.
Maintenance	UPS Unloaded	1. Close Breaker 1. 2. Turn On UPS
Maintenance	Load Off	Open Breaker 2. (This removes power from load!)
Load Off	Maintenance	Close Breaker 2.
Load Off	Test UPS	1. Close Breaker 1. 2. Turn On UPS, if desired.
Test UPS	Load Off	1. Turn Off UPS. 2. Open Breaker 1.
Test UPS	Normal	1. Turn Off UPS. 2. Close Breaker 3. 3. Turn On UPS.
Normal	Test UPS	Open Breaker 3. (This removes power from load!)
Normal	Test Battery	Open Breaker 1. Battery will discharge while Breaker 1 is open.
Test Battery	Normal	Close Breaker 1.

6. MAINTENANCE

Regular care will assure maximum availability of power.

The Transformer Cabinets have exhaust fans. We recommend that these fans be replaced every two years.

Keep the ventilation openings in the cabinet free of dust and debris.

Wipe the cabinet exterior with a soft cloth, slightly dampened with water, to remove dust.

Consider performing periodic infrared temperature measurements on the circuit breaker terminations. This will require access to the cabinet interior. There are hazardous voltages present and any work must be performed using caution. Only trained service personnel should perform this work. Elevated temperatures of the terminations usually are the sign of a loose connection, but can also signal that a breaker is failing. Loose connections should only be serviced after removal of power.

If the system is powered down, consider removing accumulated dust from the cabinet interior using a vacuum cleaner.

7. TECHNICAL SPECIFICATIONS

Table 5 - Technical Specifications

Environmental				
Altitude	De-rate load capability above 1000 meters 1% per 100 meters.			
Operating Temperature	40° C Maximum			
Humidity	Maximum 95%RH, Non-condensing			
Electrical	65 kVA	80kVA	100kVA	125kVA
Rated voltage	480/277	480/277	480/277	480/277
Rated Current	89A	109A	136A	160A
Breaker Rating	125A	150A	175A	200A
Minimum Wire Size	INPUT	1/0 AWG	2/0 AWG	3/0 AWG
		#2 AWG	1/0 AWG	2/0 AWG
OUTPUT				4/0 AWG
Heat Rejection – Less than (BTU/Hr)	650	800	1000	1250

Table 6 - Wire Size Requirements and Maximum Current Ratings

*Wire must be rated 75°C or higher

480 V Input:				
UPS rating (kVA)	Rated Current (A)	Supply Breaker (A)	Minimum Wire Size	Ground Wire Size
65	89	125	1/0	#6
80	109	150	2/0	#6
100	136	175	3/0	#6
125	160	200	250 kcmil	#4
480 V Output:				
UPS rating (kVA)	Rated Current (A)	Load Breaker (A)	Minimum Wire Size	
65	78	125	#2	
80	96	150	1/0	
100	120	175	2/0	
125	150	200	4/0	

208 V Input:				
UPS rating (kVA)	Rated Current (A)	Supply Breaker (A)	Minimum Wire Size	Ground Wire Size
65	209	300	500 kcmil or 2 X 4/0	#4
80	256	350	2 X 350 kcmil	#3
100	317	400	2 X 350 kcmil	#3
125	360	450	2 X 500 kcmil	#2
208 V Output:				
UPS rating (kVA)	Rated Current (A)	Load Breaker (A)	Minimum Wire Size	
65	180	225	400 kcmil or 2 X 2/0	
80	222	300	500 kcmil or 2 X 4/0	
100	277	350	2 X 250 kcmil	
125	346	450	2 X 500 kcmil	

Table 7 - Terminal Tightening Torques

UPS CONNECTIONS TERMINAL TORQUE

Wire Size	Torque
#4 AWG – 350 kcmil	275 inch - pounds

UTILITY AND LOAD CONNECTIONS TERMINAL TORQUE

Wire Size	Torque
#4 AWG – 500 kcmil	375 inch - pounds

GROUND LUG TORQUE

Wire Size	Torque
#6 AWG – 350 kcmil	275 inch - pounds

LOW VOLTAGE TERMINAL TORQUE

Wire Size	Torque
# 26-10 AWG	5.3 – 7.0 inch - pounds